# Disabled Persons Toilet Alarm User Guide



To be completed by the installation engineer:

User:	
Sito a	ddrass

If maintenance is required please contact:

Company: \_\_\_\_\_

Address: \_\_\_\_\_

Telephone: \_\_\_\_\_

The installation engineer should complete the relevant sections overleaf before handing this document to the user.

## USER GUIDE



### **BASIC OPERATION**

#### Raising an alarm



The distressed person raises an alarm by pulling the cord of the ceiling pull unit



The ceiling pull's red reassurance LED illuminates to reassure the user that an alarm has been made



Additional feedback that an alarm has been raised is provided inside the WC via the Remote Reset Point's sounder and reassurance LED





The one zone call controller's 'CALLING' LED illuminates and its sounder activates to let staff know that someone is in need of assistance

The following equipment (if applicable) will also activate when an alarm call is made:

#### **Resetting the system**



Pressing the call controller's reset button on your system will (checked box indicates operation):

RESET THE SYSTEM IN MUTE THE CALL CONTROLLER'S SOUNDER IN HAVE NO EFFECT

#### We recommend the system is tested on a weekly/monthly basis following the above procedure to ensure correct operation.

Approved Document No: DNU0951000 Rev 1 • Page 2 of 2